



TO FIRMLY RETAIN DRYER IN CHAIR:

***LOCATE DRYER CLIPS 1" FROM TOP OF
THE DRYER CHAIR. TAP THE "POINTS"
INTO THE WOOD & INSTALL WITH THE
SCREWS PROVIDED.***

 Collins Manufacturing
2000 Bowser Road
Cookeville, TN 38506

DRYER INSTALLATION